

Action Glossary

Overview

Each of the 16 messages can be mapped to an action executed on the MC6. This glossary provides the descriptions for the list of actions.

- Overview
- Press
- Release
- Long Press
- Long Press Release
- Double Tap
- Double Tap Release
- Long Double Tap
- Long Double Tap Release
- Release All
- Long Press Scroll

Press

A single tap to the switch.

A `Long Press` action will also execute a `Press` action. Hence, if you want to execute 2 different actions with a `Press` and `Long Press` message, you should use a `Release` and `Long Press` message instead.

Release

Releasing the switch after a `Press` action.

Long Press

A single tap to the switch that is held down for at least 600ms.

Long Press Release

Releasing the switch after a `Long Press` action.

Double Tap

A double consecutive tap to the switch.

If a Preset is programmed with a `Double Tap`, there will be a slight delay in sending out messages programmed with other actions such as `Press`, as the controller needs to determine if a double tap action has been executed.

Double Tap Release

Releasing the switch after a `Double Tap` action.

Long Double Tap

A double consecutive tap to the switch that is held down for at least 600ms.

Long Double Tap Release

Releasing the switch after a Long Double Tap action.

Release All

This action groups Release and Long Press Release together.

Long Press Scroll

Available from firmware v3.7 onwards

Messages will be repeatedly engaged while the switch is held down.